





Dell Premier Rechargeable Wireless Mouse MS7421W


Quick Start Guide




1



3




4





2

1




2




2*


1




2





3




3



3✂



<https://www.dell.com/support/drivers>



<https://www.dell.com/support>

https://www.dell.com/regulatory_compliance

