




EN	Adapter plate	NO	Adapter plate
NL	Adapterplaat	SE	Adapteråplatta
DE	Adapterplatte	FI	Adapterilevy
FR	Plaque d'adaptation	PL	Phyta adaptera
IT	Piastra adattatrice	CS	Adaptérová deska
ES	Placa adaptadora	SK	Adaptérová doska
PT	Placa adaptadora	RO	Placă adaptoare
DK	Adapterplade		



FPMA-LIFT100



75x75 mm
(mount)



75x75 - 100x100 mm
(monitor)




0-8 kg |
0-17.6 lbs



0-17.7 cm

PARTS



A. (x1)



M-A, M4x12
(x4)




M-B, M5x12
(x4)



M-C, D5
(x4)



STEP 1

- EN** Detach the VESA plate from the adapter and attach the VESA plate on the monitor mount
- NL** Maak de VESA plaat los van de adapter en bevestig de VESA plaat op de monitorsteun
- DE** Lösen Sie die Schraube um die VESA Platine von der Schiene zu lösen und montieren Sie die VESA Platine an der Monitorhalterung
- FR** Dévisser la plaque VESA de l'adaptateur. Fixer la plaque VESA sur le support du moniteur
- IT** Svita la piastra VESA dall'adattatore fissi la piastra VESA sul supporto del monitor
- ES** Desenrosque la placa VESA del adaptador. Coloque la placa VESA en el soporte del monitor
- PT** Desaparafusar a placa VESA do adaptador. Anexe a placa VESA na montagem do monitor
- PL** Odkręć płytkę VESA od adaptera. Przymocuj płytkę VESA do uchwyty monitora





STEP 2

- EN** Attach the adapter to the screen
- NL** Bevestig de adapter op het scherm
- DE** Schrauben Sie die Schiene an den Monitor
- FR** Fixer l'adaptateur à l'écran
- IT** Collegare l'adattatore allo schermo
- ES** Conecte el adaptador a la pantalla
- PT** Anexe o adaptador à tela
- PL** Zamocuj adapter do monitora



STEP 3

- EN Mount the screen and secure screw
 NL Monteer scherm en draai schroef aan
 DE Montieren Sie den Monitor an der Stange und sichern Sie ihn mit der Schraube
 FR Monter l'écran et fixer la vis
 IT Montare lo schermo e fissare la vite
 ES Monte la pantalla y asegure el tornillo
 PT Montar a tela e coloque o parafuso seguro
 PL Zamocuj monitor i zabezpiecz śrubkami



STEP 4

- EN Adjust the screen in the desired height position
 NL Stel het scherm op de gewenste hoogte in
 DE Stellen Sie die gewünschte Höhe ein
 FR Régler l'écran dans la position de hauteur désirée
 IT Regolare lo schermo nella posizione desiderata dell'altezza
 ES Ajuste la pantalla en la posición de altura deseada
 PT Ajuste a tela na posição de altura desejada
 PL Dostosuj monitor do pożądanej wysokości

