





## Parts List



A x 1



B x 2



C x 4



Silver  
D x 4




Silver  
E x 4




Yellow Zinc  
F x 4




G x 4




H x 1




I x 1



J x 1



K x 2




L x 1


## Intel Installation Guide

1

a LGA1200/1156/1155/  
1151/1150  
b LGA1851/1700



a LGA1200/1156/1155/  
1151/1150  
b LGA1851/1700



2




LGA1851/1700

or


LGA1200/115X

or


LGA2600/2011




3




4




5



6



# AMD Installation Guide



## Fan & MB SYNC Installation Guide

**CAUTION** Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. Connecting the wrong end can damage the fans.

