


Neomounts®




THINCLIENT-05

EN NUC/ thin client holder	SE NUC/ tunn klient hållare
NL NUC/ thin client houder	FI NUC/ thin client teline
DE NUC/ Thin Client Halterung	PL Uchwyt na NUC/ Thin Client
FR Support NUC/ client léger	CS Držák na jednotku NUC/ tenkého klienta
IT Supporto NUC/ thin client	SK Držiak na NUC/ počítač typu tenký klient
ES Soporte para NUC/ thin client	RO Suport pentru NUC/ client subțire
PT Suporte NUC/ thin client	
DK NUC/ tynd klient holder	
NO NUC/ tynn klient holder	

THINCLIENT-05

PARTS



A. M5
(x1)




B. M4x10
(x4)



C. M4
(x4)

STEP 1

- EN Attach the mount to the pole
 NL Bevestig de beugel aan de paal
 DE Montage die Halterung an der Stange
 FR Fixez le support
 IT Fissare il supporto
 ES Fijar el soporte
 PT Fixar o suporte
 PL Zamocuj uchwyt



STEP 2

- EN Attach the PC/ Thin Client holder to the mount
 NL Bevestig de PC/ Thin Client houder aan de beugel
 DE Fixieren des PC/ Thin Client-Halters an die Halterung
 FR Fixer le support PC/ Thin Client sur le support
 IT Fissare il supporto PC/ Thin Client sul supporto
 ES Conecte el soporte PC/ Thin Client en el soporte
 PT Anexe o suporte do PC/ Thin Client no suporte
 PL Przytwierdź mocowanie do PC/ Thin Client do uchwytu

