Certified for

### **Microsoft Teams**

How-to video



# BH76 Plus

Yealink

Bluetooth Headset



Quick Start Guide V1.4



Please update the headset to the latest version via Yealink USB Connect (PC) or Yealink Connect (APP) before using.

## 1 Package List

Standard







BH76

On-ear Ear Cushion

Carrying Case









BT51-C Dongle

- USB C/A Adapter
- USB Charging Cable Quick Start Guide

Optional






BHC76 Wireless Charging Stand

Note: We recommend that you use the included accessories, and other accessories may have compatibility issues that prevent them from working properly.


## 2 Charging





Note: We recommend to fully charge the headset when using it for the first time. The BHC76 is compatible with devices that support QI wireless charging, such as wireless charging mobile phones and headsets.

### **LED Indicator Status**




Note: It takes two hours for USB charging and three hours for wireless charging to be fully charged.

## 3 Power on/off



### 4 Pairing and Connecting Device

No Built-in Bluetooth Device




Already pre-paired when leaving the factory, automatically connected


### Built-in Bluetooth Device

### Step1: Enter Pairing Mode


### • Power On State



Step2: Select the Headset from Your Bluetooth Device




## **5** Call Controls and Busylight




Note: Only the Teams edition can connect to Teams.

### 6 Music Controls



8 Sound Control



Note:

- You can set the level of noise cancellation on Yealink USB Connect (desktop client) or Yealink Connect (mobile app).
- If you are in Noise Canceling Mode, you might not hear the ambient sound. It depends on ambient conditions and the type or volume of audio playback Do not use the headset in places where the inability to hear ambient sounds would be dangerous.

## 9 Replace Ear Cushions

• On-ear to Over-ear



Use your fingers to disassemble the headset and on-ear cushion



Align the over-ear cushion with the headset

• Over-ear to On-ear



Use your fingers to disassemble the headset and over-ear cushion



Align the on-ear cushion with the headset



Remove the on-ear cushion from the headset



Press the headset and over-ear cushion tightly



Remove the over-ear cushion from the headset



Press the headset and on-ear cushion tightly

## **10** Software Management

Yealink USB Connect (PC)



Download it from the Yealink website https://www.yealink.com/product/yuc.

Note: It needs to be used with Yealink USB Connect of version 0.34.x.x or higher.

### Yealink Connect App (Mobile)

Apple and the Apple logo are trademarks of Apple Inc.



Yealink When the PC 14200 mercine and the terror of these side MEAN AMARAM ACCO 66 Declaration of Conformity 14 (7284); 24000 (410) Model (51) [1] 1.640 121 - 2000  $(1+1) \leq (1+1) \leq 2N \leq n$ Along the state of the second second second the states and where it is a set of the set of t server the landsteries frame. terbine for the termination The close had been MARKEN C. we are recombined by the transmission of the transmission of the barrier of the barrier of the barrier of the b [3] Street Review Control (1997) 11 (2017) 11 (2017) 11 (2017) - conformation 制度的现在分词 网络白垩合 医白垩合 网络白垩合 In 2005 DEPENDENT IN ELC. 31, 3225 HE REPORTED A LODGE CHARGES FOR A LODGE CHARLES FROM C1 (10) 477 (47) 73 (24) PATRONING A 2 PATRONICO DE PRODUCES ACTIVITAD GRANTERING & OTHER ATE 100 01 11 1 2 3 4 5 4 1 1 1 1 5 10 1 1 4 5 11 1 and a state of the TARCENE A reden 2830 Sold and Full Bill, 852 a. J. P. Hull of the second The first a first \$200 control strategies of the condition with reada construction for an ARM SPACE Reader (1937) 11 - 1 - San an Tala er alle - Tala - Alle - The San Alle - The San Antonia ( 1944) and an appendix ( 1944) Renderer TO NATEWORD PERFORMANCE LEADER AND LEADER AND A LEADER AND A and restance that interfact each state and the state of the second Through The sector of the state of the state of the first state of the state o NY 15 1 1 16 DOTE: N

and the second second second second second

114

#### Regulatory Notices

Operating Ambient Temperatures

- Operating temperature: +32 to 104°F (0 to 40°C)
- Relative humidity: 5% to 90%, noncondensing
   Storage temperature: -22 to +160°F (-30 to +70°C)

#### Warranty

Our product warranty is limited only to the unit itself, when used normally in accordance with the operating instructions and the system environment. We are not liable for damage or loss resulting from the use of this product, or for any claim from a third party. We are not liable for produces with Vesaitk device arising from the use of this product, we are not liable for financial damages, lost profits, claims from thuid parties, etc., arising from the use of this product.

#### Explanation of the symbols

DC symbol

is the DC voltage symbol

WEEE Warning symbol

To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic

equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as

unsorted municipal waste and have to collect such WEEE separately.

#### Restriction of Hazardous Substances Directive (RoHS)

This device complies with the requirements of the EU RoHS Directive. Statements of compliance can be obtained by contacting support@yealink.com.

#### Safety Instructions

Save these instructions. Read these safety instructions before use!

#### General Requirements

- Before you install and use the device, read the safety instructions carefully and observe the situation during operation.
- During the process of storage, transportation, and operation, please always keep the device dry and clean, avoid collision and crash.
- Please attempt not to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair.
- Please refer to the relevant laws and statutes while using the device. Legal rights of others should be respected as well.

#### Environmental Requirements

- Place the device at a well-ventilated place. Do not expose the device under direct sunlight.
- . Keep the device dry and free of dusts
- Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials.
- Keep the device away from any heat source or bare fire, such as a candle or an electric heater.

#### Operating Requirements

- . Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accidental swallowing.
- Please use the accessories provided or authorized by the manufacturer only.
   The power supply of the device shall meet the requirements of the input voltage of the device. Please use the provided surge protection power socket
- Voltage of the device. Please use the provided surge protection power socket only.
  Before plugging or unplugging any cable, make sure that your hands are
- Do not spill liquid of any kind on the product or use the equipment near water,
- Di noi spii inquia oi any kino on the product or use the equipment near water, for example, near a bathtub, washbowl, kitchen sink, wet basement or near a swimming pool.
- During a thunderstorm, stop using the device and disconnect it from the power supply. Unplug the power plug and the Asymmetric Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike.
- If the device is left unused for a rather long time, disconnect it from the power supply and unplug the power plug.
- When there is smoke emitted from the device, or some abnormal noise or smell, disconnect the device from the power supply, and unplug the power plug immediately.
- · Contact the specified maintenance center for repair.
- Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- Before connecting a cable, connect the grounding cable of the device first. Do
  not disconnect the grounding cable until you disconnect all other cables.

#### Battery Requirements

- Do not immerse the battery into water, which could short-circuit and damage the battery.
- Do not expose the battery to an open flame or leave the battery where it could be subjected to extremely high temperatures, which could cause the battery to explode.
- . Do power the handset off before removing the battery.
- Do not try to use the battery for the power supply of any device other than this handset.



 Do not open or mutilate the battery, released electrolyte is corrosive and may cause damage to your eyes or skin.

- Use only the rechargeable battery pack delivered with the handset or those rechargeable battery packs expressly recommended by Yealink.
- Defective or exhausted battery should never be disposed of as municipal waste. Return old battery to the battery supplier, a licensed battery dealer or a designated collection facility.

#### Cleaning Requirements

- · Before cleaning the device, disconnect it from the power supply.
- . Use a piece of soft, dry and anti-static cloth to clean the device.
- . Keep the power plug clean and dry.

#### Troubleshooting

The unit cannot supply power to Yealink device.

- There is a bad connection with the plug.
- 1. Clean the plug with a dry cloth.
- 2. Connect it to another wall outlet
- The usage environment is out of operating temperature range.

1. Use in the operating temperature range

The cable between the unit and the Yealink device is connected incorrectly. 1. Connect the cable correctly.

- You cannot connect the cable property.
- You may have connected a wrong Yealink device.
- 2 Use the correct power supply
- Some dust, etc., may be in the port.
- Clean the port.

Contact your dealer or authorized service facility for any further questions. FCC CAUTION:

This device complete with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class de gialal divelo, poursant to part 15 of the PCG Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation installated and used in accordance with the instruction, may accurate harmful interference to radio communications. However, there is no guarantee that interference to radio communications. However, there is no guarantee that interference to radio cours in a particular installation. If this equipment do cours in a particular installation. If this equipment does cause harmful interference individe a state of the radio or the levision reception, which can be determined by turning the equipment of bootnot measure.

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### ISED WARNING:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présentappareilestconforme aux CNR d'industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes : (1) rappareil ne doit pas produre de brouillage; et (2) rituitisature de l'appareiloti accepter tout brouillageradioelectriquesubi, mêmesi le brouillageest susceptible d'encompromettre le horicionnement.

This Class B digital apparatus complies with Canadian ICES-003. Cetappareilnumérique de la classe B estconformeà la norme NMB-003 du Canada.

Les communications effectuées au moyen de cetappareil ne sont pas nécessairement protégées des indiscrétions.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Déclarationd'exposition aux radiations: Cetéquipementestconforme aux limitesd'exposition aux rayonnements ISED Canada établies pour unerwironnement non contrôlé. Cetéquipementdoitêtreinstallé et utilisé avec un minimum de20cm de distance entre la source de rayonnement et votre corps.

EU Regulatory Information Support Frequency Bands and Power: Bluetooth 2.4GHz< 20 dBm

#### Contact Information

YEALINK KETWORK TECHNOLOGY COLITD. Na666 Hu'an Rd, Hull District Xiamen City, Fujian, PR, China YEALINK (EUROPE) NETWORK TECHNOLOGY B J. Sir Winston Churchillin 298 k, 2288DC Rijawjk YEALINK (IGSA NETWORK TECHNOLOGY COLITD) 999 Reachtree Street Suite 2300, Fulton, Atlanta, GA, 30309, USA Made in China

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO., LTD.

Web: www.yealink.com Copyright©2024YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD. All rights reserved.